

Factory Wheel with ididit's E-Body Steering Wheel Adaptor

For Part #'s: 2209320020, 2209320030, 2209320040, 2209320051

1. Check to verify the driving wheels are straight. On the top of the column there is a white tube sticking out of the column. This tube should be between the 10:30 and 11:00 o' clock position. When the wheels are straight. If this is not true gently turn the white plastic tube to be in this position. Set the adaptor on the shaft of the column, this may require you to rotate a little to the closest tooth on the spline.
2. Install the 9/16 nut and torque to 45 FT. LBS.
3. Install the horn wire by aligning the catch pin and push in, then turn 1/8 of a turn clockwise. (See Figure 1)
4. Now use the three provided bolts to install the wheel.
5. Use the original three screws that held the horn mechanism in place to re-secure it. (See Figure 2)
6. Now connect the wire to the electrical tab, and finally push the button over the contact.



(Figure 1)



(Figure 2)

Aftermarket Replacement Wheels

If using the Grant Tuff Grip aftermarket replacement wheel, with our adaptor. You will need these additional parts for your horn to work properly. (See Figure 3) We have a kit that includes all of these components. Kit part number is: 2611010010

If you have any questions about installation you can contact ididit's tech line and we will be happy to walk you through any of the processes. Call (517) 424-0577 or visit us online and click "Contact Us".



(Figure 3)



www.ididitinc.com

610 S. Maumee St. Tecumseh, MI 49286
PH: (517) 424-0577 FAX: (517) 424-7293

Revised: 6/18/2008
Instruction #: 8000-010-006